



POV Power (POV149)

PLEASE READ THE INFORMATION AND FOLLOW ALL INSTRUCTIONS BEFORE USING THIS PRODUCT.

CARE:

- Clean and inspect after every use.
- Inspect all plug terminals to make sure that they are clean and in proper alignment.
- Never force a connection.
- Always hold the cable end to connect and disconnect.
- Store your equipment in a cool, dry place.
- Check all cables for cracks or exposed wires; if a cable is suspect, discard and replace.

CAUTIONS:

- Always unplug the charger when not in use.
- Always replace frayed or damaged wires and broken plugs immediately.
- Do not short-circuit the metal contacts of the battery pack.
- Do not disassemble, deform, or reconstruct any part of the battery kit.

NOTES:

- It is normal for the power supply to become warm during regular operation.
- Always keep metal contacts clean by wiping the surfaces with a dry, soft, and clean cloth.



POV Power (POV149)

OPERATING INSTRUCTIONS:

Use:

1. Remove all batteries from the POV recorder.
2. Install power supply unit on battery hatch. Secure with side tabs.
3. Plug in SAE plug of desired cable to power supply unit.
4. Plug or attach cable to 12v power source.

Cigarette Lighter Cable:

1. Use only with 12v power source.
2. LED light indicates when powered.

Hardwire Cable:

1. Use only with 12v power source.
2. Customer replaceable 5A-250V fuse in-line with positive connector.

Tips:

Be sure to save your video clip and stop recording before turning off or disconnecting from the power source. If not done, you will risk losing the current video clip.

In order to conserve power (and not drain battery), turn the POV recorder off and unplug from the power source when not in use.